



Step 1



Step 2



Step 3



Step 4

Step 1 - Build frames with MDF at 36" wide x 96" tall. Face frame is 4" wide and back frame is 2" wide. use glue and finish nails to hold frame together.

Step 2 - Buy screen door replacement screen at Lowes or Home Depot and cut to fit the outside edge of the frame. standard roll comes 36" wide.

Step 3 - compress the screen door sheet into a ball the more wrinkles the better.

Step 4 - stretch sheet out and staple 2" from the outside edge. Use a lot of staples

Step 5 - Stand up and aim your LED or par in front or behind the screen door.